



48 Spencer Street
Lebanon, NH 03766, USA
Tel: 603-448-1562
Fax: 603-448-3216
Email: geokon@geokon.com
<http://www.geokon.com>

Instruction Manual
Model 8020-59PLC
Programmable Logic Controller Interface



No part of this instruction manual may be reproduced, by any means, without the written consent of GEOKON®.

The information contained herein is believed to be accurate and reliable. However, GEOKON® assumes no responsibility for errors, omissions or misinterpretation. The information herein is subject to change without notification.

Copyright © 2022 by GEOKON®
(Doc Rev B, 05/10/22)

Warranty Statement

GEOKON warrants its products to be free of defects in materials and workmanship, under normal use and service for a period of 13 months from date of purchase. If the unit should malfunction, it must be returned to the factory for evaluation, freight prepaid. Upon examination by GEOKON, if the unit is found to be defective, it will be repaired or replaced at no charge. However, the WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion or current, heat, moisture or vibration, improper specification, misapplication, misuse or other operating conditions outside of GEOKON's control. Components which wear or which are damaged by misuse are not warranted. This includes fuses and batteries.

GEOKON manufactures scientific instruments whose misuse is potentially dangerous. The instruments are intended to be installed and used only by qualified personnel. There are no warranties except as stated herein. There are no other warranties, expressed or implied, including but not limited to the implied warranties of merchantability and of fitness for a particular purpose. GEOKON is not responsible for any damages or losses caused to other equipment, whether direct, indirect, incidental, special or consequential which the purchaser may experience as a result of the installation or use of the product. The buyer's sole remedy for any breach of this agreement by GEOKON or any breach of any warranty by GEOKON shall not exceed the purchase price paid by the purchaser to GEOKON for the unit or units, or equipment directly affected by such breach. Under no circumstances will GEOKON reimburse the claimant for loss incurred in removing and/or reinstalling equipment.

Every precaution for accuracy has been taken in the preparation of manuals and/or software, however, GEOKON neither assumes responsibility for any omissions or errors that may appear nor assumes liability for any damages or losses that result from the use of the products in accordance with the information contained in the manual or software.

TABLE of CONTENTS

1. INTRODUCTION	1
2. CONNECTOR PINOUT AND SIGNAL DESCRIPTION:	2
APPENDIX A. SPECIFICATIONS:.....	3

TABLES

TABLE 1 - J1 PINOUT AND SIGNALS DESCRIPTION	2
TABLE 2 - J2 PINOUT AND SIGNALS DESCRIPTION	2
TABLE 3 - SPECIFICATIONS	3

1. Introduction

The 8020-59PLC provides the capability to control the 8020-59 VW to Analog Converter and/or the 8032 Multiplexer via relay closures (Ground Referenced) as provided by most Programmable Logic Controllers (PLC).

Relay contacts “bounce” when opened or closed, resulting in multiple low to high (0V → 5V) or high to low (5V → 0V) CMOS logic transitions instead of one clean transition. Relay closures input into the 8020-59PLC from the PLC are “de-bounced” and translated into the required 0/5V CMOS logic level signals for the ENABLE and CLOCK control signals. Conversely, the READY 0/5V CMOS logic level control signal output from the 8020-59 is translated into a relay closure (optical relay) for connection back to the PLC.

The 8020-59PLC also provides a convenient wiring panel to connect the 8020-59 and the 8032 to the PLC with L.E.D. status indicators to display the state of the ENABLE, CLOCK and READY control signals.

2. Connector Pinout and Signal Description:

The J1 connector (8020-59/8032 side) pinout and signals descriptions are outlined in Table 1.

POSITION	LABEL	DESCRIPTION
1	+12V	+12V Power: Connect to the 8020-59 (pin 6)
2	GND	GND: Connect to the 8020-59 (pin 7)
3	EN	ENABLE: Connect to the 8020-59 (pin 13)
4	CLK	CLOCK: Connect to the 8020-59 (pin 14)
5	RDY	READY(Valid): Connect to the 8020-59 (pin 12)
6	GND	GND: Connect to the 8020-59 (pin 1)
7	GND	GND: Spare GND connection
8	GND	GND: Spare GND connection
9	+12V	+12V Power: Connect to the 8032 I/O connector (J5 pin 6)
10	GND	GND: Connect to the 8032 I/O connector (J5 pin 7)
11	EN	ENABLE: Connect to the 8032 I/O connector (J5 pin 8)
12	CLK	CLOCK: Connect to the 8032 I/O connector (J5 pin 9)

Table 1 - J1 Pinout and Signals Description

The J2 connector (PLC side) pinout and signals descriptions are outlined in Table 2.

POSITION	LABEL	DESCRIPTION
1	12V	+12V Power: Connect to the PLC +12V power supply
2	GND	GND: Connect to the PLC power supply ground
3	ENABLE	ENABLE: SPST Relay #1 pole 1 (normally open)
4	GND	GND: SPST Relay #1 pole 2 (normally open)
5	CLOCK	CLOCK: SPST Relay #2 pole 1 (normally open)
6	GND	GND: SPST Relay #2 pole 2 (normally open)
7	READY 1	READY pole 1: SPST Relay closure to PLC – normally open
8	READY 2	READY pole 2: SPST Relay closure to PLC – normally open
9	GND	GND: Connect to PLC power supply ground

Table 2 - J2 Pinout and Signals Description

APPENDIX A. SPECIFICATIONS:

PHYSICAL	
Dimensions:	111 x 109 x 37 mm (with cover)
Weight:	6 oz.
Operating Temperature:	-20 to +80 °C
POWER REQUIREMENTS (@+25° C)	
+12V Input Voltage Range:	9 to 15 VDC (12V nominal)
Operating Current:	30 mA @ +12 V
Sleep Current:	20 uA @ +12 V
VALID RELAY CLOSURE OUTPUT	
Type:	PhotoMos Solid-State Relay
On Resistance:	50Ω (max.)
Load Current:	100 mA (continuous) 300 mA (peak)
Load Voltage:	400 V (max.)
Isolation Voltage:	1500 VAC (max.)

Table 3 - Specifications