Model 8800 Series

GeoNet Wireless Data Hosting System Instruction Manual





©2021, GEOKON. All rights reserved. Document Revision: Z | Release Date: 06/21/22

WARRANTY STATEMENT

GEOKON warrants its products to be free of defects in materials and workmanship, under normal use and service for a period of 13 months from date of purchase. If the unit should malfunction, it must be returned to the factory for evaluation, freight prepaid. Upon examination by GEOKON, if the unit is found to be defective, it will be repaired or replaced at no charge. However, the WARRANTY IS VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion or current, heat, moisture or vibration, improper specification, misapplication, misuse or other operating conditions outside of GEOKON's control. Components that wear or are damaged by misuse are not warranted. This includes fuses and batteries.

GEOKON manufactures scientific instruments whose misuse is potentially dangerous. The instruments are intended to be installed and used only by qualified personnel. There are no warranties except as stated herein. There are no other warranties, expressed or implied, including but not limited to the implied warranties of merchantability and of fitness for a particular purpose. GEOKON is not responsible for any damages or losses caused to other equipment, whether direct, indirect, incidental, special or consequential which the purchaser may experience as a result of the installation or use of the product. The buyer's sole remedy for any breach of this agreement by GEOKON or any breach of any warranty by GEOKON shall not exceed the purchase price paid by the purchaser to GEOKON for the unit or units, or equipment directly affected by such breach. Under no circumstances will GEOKON reimburse the claimant for loss incurred in removing and/or reinstalling equipment.

Every precaution for accuracy has been taken in the preparation of manuals and/or software, however, **GEOKON** neither assumes responsibility for any omissions or errors that may appear nor assumes liability for any damages or losses that result from the use of the products in accordance with the information contained in the manual or software.

No part of this instruction manual may be reproduced, by any means, without the written consent of GEOKON. The information contained herein is believed to be accurate and reliable. However, GEOKON assumes no responsibility for errors, omissions or misinterpretation. The information herein is subject to change without notification.

The GEOKON® wordmark and logo are registered trademarks with the United States Patent and Trademark Office.

TABLE OF CONTENTS

1. INTRODUCTION	1
1.1 MODEL IDENTIFICATION	
1.2 MODEL LIST	
1.3 MESH TILT LOGGER SERIAL NUMBERS	
2. NETWORK COMPONENTS	4
2.1 CELLULAR GATEWAY	4
2.2 LOCAL GATEWAY	4
2.2.1 RS-232 (880X-XX-SUP-232)	4
2.2.2 USB (880X-XX-SUP-USB)	
2.3 SINGLE-CHANNEL LOGGER	
2.3.1 10-PIN CONNECTOR (880X-XX-01C-10P)	
2.3.2 GLAND SEAL (880X-XX-01C-CBL)	6
2.4 MULTIPLE-CHANNEL LOGGERS	6
2.4.1 SINGLE-CHANNEL (8800-XX-ADR-CBL)	6
2.4.2 FOUR-CHANNEL (880X-XX-04C-CBL)	7
2.4.3 EIGHT-CHANNEL (880X-XX-08C-CBL)	7
2.4.4 ADDITIONAL INFORMATION	
2.5 MESH TILT LOGGER (880X-XX-TLT-NAP)	8
2.6 ACCESSORIES	8
	0
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES	9 9 12 12 12
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES	9 9 12 12 12 12 12
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY 3.2.1 POWER CONCERNS	
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY 3.2.1 POWER CONCERNS 3.2.2 POWER THE GATEWAY	9 9 12 12 12 12 12 12 12 12 12 12 13 13 13
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY 3.2.1 POWER CONCERNS 3.2.2 POWER THE GATEWAY 3.2.3 SEAL THE GATEWAY	9 9 12 12 12 12 12 12 12 12 12 12 13 13 13 13 13
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY 3.2.1 POWER CONCERNS 3.2.2 POWER THE GATEWAY 3.2.3 SEAL THE GATEWAY 3.2.4 SET THE NETWORK TIME	9 9 12 12 12 12 12 12 12 12 13 13 13 13 13 14 15
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY 3.2.1 POWER CONCERNS 3.2.2 POWER THE GATEWAY 3.2.3 SEAL THE GATEWAY 3.2.4 SET THE NETWORK TIME 3.2.5 VERIFY THE NETWORK TIME	9
2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS 2.8 NETWORKS 3. NETWORK INSTALLATION 3.1 PREPARE THE GATEWAY AND LOGGERS 3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES 3.1.2 REMOVE THE COVERS FROM ALL DEVICES 3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES 3.2 CONFIGURE THE GATEWAY 3.2.1 POWER CONCERNS 3.2.2 POWER THE GATEWAY 3.2.3 SEAL THE GATEWAY 3.2.4 SET THE NETWORK TIME 3.2.5 VERIFY THE NETWORK TIME 3.2.6 RECORD THE GATEWAY SERIAL NUMBER	9

3.3.1 POWER THE LOGGERS	
3.3.2 VERIFY THE NETWORK CONNECTION OF THE LOGGERS	
3.4 MOUNTING THE DEVICES	
3.4.1 MOUNTING LOCATION CONSIDERATIONS	
3.4.2 GROUND THE GATEWAY AND LOGGERS	17
3.5 CONNECT THE SENSORS TO LOGGERS	
3.5.1 MAKING CABLE GLAND CONNECTIONS	
3.5.2 MAKING 10-PIN CABLE CONNECTIONS	
3.5.3 NOTES ABOUT MULTIPLE-CHANNEL AND ADDRESSABLE LOGGERS	
3.5.4 SEAL THE LOGGERS	
3.5.5 RECORD LOGGER AND SENSOR SERIAL NUMBERS	
3.6 CELLULAR GATEWAY COMMISSIONING	
3.7 DEPLOYMENT MODE	
3.7.1 PLACING THE GATEWAY AND ADDING LOGGERS	
3.8 STATUS BUTTON FUNCTIONALITY	
4. MAINTENANCE	
4.1 PREVENTING WATER FROM ENTERING THE ENCLOSURES	
4.2 BATTERY LIFE	
4.3 REPLACING BATTERIES	
4.4 LIGHTNING PROTECTION	
5. MODEL 8800-2-4B ADD-ON MODULE	
5.1 INTRODUCTION	
5.2 INSTALLATION OVERVIEW	
5.3 IP ADDRESS CONFIGURATION	
APPENDIX A. SPECIFICATIONS	
A.1 GATEWAY SPECIFICATIONS	
A.2 LOGGER SPECIFICATIONS	
A.3 NETWORK SPECIFICATIONS	
A.4 MESH TILT LOGGER SPECIFICATIONS	
APPENDIX B. CONNECTOR PINOUTS	
B.1 GAUGE CABLE	
B.1.1 GLAND SEAL MESH VW LOGGERS (880X-XX-01C-CBL)	
B.1.2 10-PIN BULKHEAD MESH VW LOGGERS (880X-XX-01C-10P)	
B.1.3 MESH ADDRESSABLE LOGGERS (880X-XX-ADR-CBL)	
B.2 COMMUNICATION CONNECTIONS	

B.2.1 RS-232 (880X-XX-SUP-232)	
B.2.2 USB (880X-XX-SUP-USB)	
APPENDIX C. THERMISTOR TEMPERATURE DERIVATION	
APPENDIX D. TROUBLESHOOTING	
APPENDIX E. FIRMWARE UPDATE	
E.1 PROCEDURE	
E.2 FIRMWARE TROUBLESHOOTING	
APPENDIX F. SOLAR PANEL KIT	
F.1 SELECT A LOCATION	
F.2 ASSEMBLE THE MOUNTING BRACKET	
F.3 INSTALL THE MOUNTING BRACKET	
F.4 SECURE THE SOLAR PANEL TO THE MOUNTING BRACKET	
F.5 CONNECT THE POWER CABLE	
F.5.1 BATTERY SWITCH	
F.5.2 MAKING THE CONNECTION	

FIGURES

FIGURE 1: SERIAL NUMBER PLACEMENT ON MESH TILT LOGGERS	3
FIGURE 2: CELLULAR GATEWAY	4
FIGURE 3: RS-232 LOCAL GATEWAY	4
FIGURE 4: USB LOCAL GATEWAY	5
FIGURE 5: 10-PIN SINGLE CHANNEL LOGGER	5
FIGURE 6: GLAND-SEAL SINGLE CHANNEL LOGGER	6
FIGURE 7: MESH ADDRESSABLE LOGGER	6
FIGURE 8: FOUR-CHANNEL LOGGER	7
FIGURE 9: EIGHT-CHANNEL LOGGER	7
FIGURE 10: MESH TILT LOGGER	8
FIGURE 11: STAR NETWORK TOPOLOGY	9
FIGURE 12: MESH NETWORK TOPOLOGY	10
FIGURE 13: WORKING AROUND OBSTRUCTIONS VIA HOPS	10
FIGURE 14: FRESNEL ZONE	11
FIGURE 15: CHANNEL SELECT SWITCHES	13
FIGURE 16: CELLULAR GATEWAY BATTERY SWITCH	14
FIGURE 17: LOCAL GATEWAY BATTERY SWITCH	14
FIGURE 18: BATTERY DETAIL	14
FIGURE 19: INSTALLING NEAR A LARGE OBJECT	16
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS	16
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS	16 17
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS	16 17 18
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD	16 17 18 19
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER	16 17 18 19 19
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT	16 17 18 19 19 20
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS	16 17 18 19 19 20 20
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS	16 17 18 19 20 20 20
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER	16 17 18 19 20 20 20 21
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE	16 17 19 20 20 20 21 21
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS	16 17 18 19 20 20 21 21
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION	16 17 18 19 20 20 21 21 21 21
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 27: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION FIGURE 32: COPY THE TOKEN	16 17 19 20 20 20 21 21 21 21 21 22
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION FIGURE 32: COPY THE TOKEN FIGURE 33: INSTALLATION ORDER	16 17 18 19 20 20 21 21 21 21 22 22 23
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION FIGURE 32: COPY THE TOKEN FIGURE 33: INSTALLATION ORDER FIGURE 34: NPORT CONFIGURATION	16 17 18 19 20 20 20 21 21 21 21 22 22 22 23 27
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION FIGURE 32: COPY THE TOKEN FIGURE 33: INSTALLATION ORDER FIGURE 34: NPORT CONFIGURATION FIGURE 35: UPDATE FIELDS	16 17 18 19 20 20 21 21 21 21 21 21 21 22 23 23
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION FIGURE 32: COPY THE TOKEN FIGURE 33: INSTALLATION ORDER FIGURE 34: NPORT CONFIGURATION FIGURE 35: UPDATE FIELDS FIGURE 36: IP ADDRESS WITH :4001 SUFFIX	16 17 18 19 20 20 21 21 21 21 21 21 21 22 23 23 23 28
FIGURE 20: INSTALLING CLOSE TO BUILDINGS OR FENCES/WALLS FIGURE 21: MOUNTING ONTO A METAL PLATE / INSIDE AN ENCLOSURE FIGURE 22: TERMINAL CONNECTIONS FIGURE 23: ACCESSING THE CLOUD FIGURE 24: CREATE A USER FIGURE 25: ADD AN ACCOUNT FIGURE 26: API ACCOUNTS FIGURE 26: API ACCOUNTS FIGURE 27: ENTER YOUR CREDENTIALS FIGURE 28: ENTER THE SERIAL NUMBER FIGURE 29: ACTIVATE CELLULAR SERVICE FIGURE 30: ENTER SENSOR SERIAL NUMBERS FIGURE 31: UPDATE THE SENSOR CONFIGURATION FIGURE 32: COPY THE TOKEN FIGURE 33: INSTALLATION ORDER FIGURE 34: NPORT CONFIGURATION FIGURE 35: UPDATE FIELDS FIGURE 36: IP ADDRESS WITH :4001 SUFFIX FIGURE 37: RS-232 CABLE CONNECTION	16 17 18 19 20 20 20 21 21 21 21 21 21 22 23 23 23 23

FIGURE 39: CHOOSE THE 'EXTRACT ALL' MENU OPTION	36
FIGURE 40: CLICK THE 'EXTRACT ALL' BUTTON	36
FIGURE 41: SELECT THE DESTINATION	36
FIGURE 42: OPEN THE GEOKON UPDATE UTILITY	36
FIGURE 43: CLICK 'SELECT FILE'	36
FIGURE 44: SELECT THE FIRMWARE TEXT FILE	37
FIGURE 45: SELECT THE COM PORT	37
FIGURE 46: CLICK 'PROGRAM'	37
FIGURE 47: SOLAR PANEL 8900-SOL-10W-BRJ	38
FIGURE 48: SOLAR PANEL KIT BOX CONTENTS	38
FIGURE 49: MOUNTING OPTIONS	39
FIGURE 50: CENTRALLY-LOCATED MOUNTING HOLES	39
FIGURE 51: MOUNTING BRACKET FASTENED CENTRALLY	40
FIGURE 52: SOLAR PANEL WITH EXTERNAL BATTERY	40

TABLES

TABLE	1: GEONET 8800 SERIES MODEL LIST	3
TABLE	2: FOUR-CHANNEL MESH VW LOGGER GAUGE/LOAD LIMITS	7
TABLE	3: EIGHT-CHANNEL MESH VW LOGGER GAUGE/LOAD LIMITS	7
TABLE	4: LEGACY COMPATIBILITY CHART	9
TABLE	5: CHANNEL SELECTION	. 13
TABLE	6: CELLULAR GATEWAY BATTERY SWITCH OPTIONS	. 14
TABLE	7: LOGGER WIRING	. 18
TABLE	8: LED INDICATOR MEANING	.24
TABLE	9: STATUS BUTTON FUNCTIONS	.24
TABLE	10: BATTERY LIFE ESTIMATES	.25
TABLE	11: GATEWAY SPECIFICATIONS	.29
TABLE	12: LOGGER SPECIFICATIONS	.29
TABLE	13: NETWORK SPECIFICATIONS	.29
TABLE	14: BIAXIAL MESH TILT LOGGER SPECIFICATIONS	. 30
TABLE	15: MESH VW LOGGER CABLE CONNECTIONS (GLAND SEAL)	.31
TABLE	16: MESH VW LOGGER CABLE CONNECTIONS (10-PIN BULKHEAD)	.31
TABLE	17: MESH ADDRESSABLE LOGGER CONNECTIONS (GLAND SEAL)	.31
TABLE	18: COMMUNICATION CONNECTIONS (RS-232)	.31
TABLE	19: COMMUNICATIONS CONNECTIONS (USB)	.31
TABLE	20: 3KΩ THERMISTOR RESISTANCE	. 32

1. INTRODUCTION

GeoNet is a low-power wireless data hosting system, designed to efficiently collect data from many points. GeoNet is especially helpful in geographically-complex locations where a wired infrastructure would be expensive or even impossible. Available network components include a Cellular Gateway, Local Gateway, single- and/or multiple-channel Mesh Vibrating Wire (VW) Loggers, Mesh Addressable Loggers, a Mesh Tilt Logger, and Agent software.

Model 8800 Series loggers collect data from GEOKON's VW gauges and sensors.

The Mesh Tilt Logger contains an integrated GEOKON biaxial tiltmeter, and functions in the same manner as other loggers.

The Cellular Gateway contains a cellular module enabling it to send sensor data to the GEOKON cloud. The device stores battery and temperature data sent from the loggers, and data from the sensors, but it does not possess sensor-reading functionality on its own. Data can be retrieved using the GEOKON cloud, or manually using a cable.

The Local Gateway is the same as the Cellular Gateway except it lacks a cellular module. Data must be retrieved manually via a direct cable connection.

FEATURES:

- Supercapacitor eliminates data blackout during battery replacement
- 26 km (6.5 km x 4 hops) range, line-of-sight
- Modular, configurable design
- Aluminum enclosure for enhanced ruggedness and weatherproofing
- Up to 12 networks per area (using unique channels)
- USB connector for firmware updates, diagnostics, and more

GEOKON recommends that you configure your network with the devices at the same location, in close proximity to each other, before you deploy them to their respective on-site positions.

An installation tutorial on the GEOKON website, https://www.geokon.com/ tutorial-videos, can help with this.



CAUTION! To satisfy FCC RF exposure requirements for mobile transmitting devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended. The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.

1.1 MODEL IDENTIFICATION

The 8800 series model numbers are composed of codes that together indicate the following information about each unit:



1.2 MODEL LIST

The list of 8800 series models is as follows:

8800-NA-LTM-USB	USB LTE-M Cellular Gateway, North America		
8800-NA-03G-USB	USB 3G Cellular Gateway, North America		
8800-NA-SUP-USB	USB Local Gateway, North America		
8800-NA-SUP-232	RS-232 Local Gateway, North America		
8800-NA-01C-CBL	Single-Channel Mesh VW Logger, Cable Gland, North America		
8800-NA-01C-10P	Single-Channel Mesh VW Logger, 10-Pin Bulkhead, North America		
8800-NA-ADR-CBL	Mesh Addressable Logger, Cable Gland, North America		
8800-NA-04C-CBL	Four-Channel Mesh VW Logger, Cable Gland, North America		
8800-NA-08C-CBL	Eight-Channel Mesh VW Logger, Cable Gland, North America		
8800-NA-TLT-NAP	Mesh Tiltmeter Logger, No Cable Entry, North America		
8800-BZ-SUP-232	RS-232 Local Gateway, Brazil		
8800-BZ-SUP-USB	USB Local Gateway, Brazil		
8800-BZ-01C-CBL	Single-Channel Mesh VW Logger, Cable Gland, Brazil		
8800-BZ-01C-10P	Single-Channel Mesh VW Logger, 10-Pin Bulkhead, Brazil		
8800-BZ-ADR-CBL	Mesh Addressable Logger, Cable Gland, Brazil		
8800-BZ-04C-CBL	Four-Channel Mesh VW Logger Cable Gland, Brazil		
8800-BZ-08C-CBL	Eight-Channel Mesh VW Logger, Cable Gland, Brazil		
8800-AU-03G-USB	USB 3G Cellular Gateway, Australia		
8800-AU-SUP-USB	USB Local Gateway, Australia		
8800-AU-SUP-232	RS-232 Local Gateway, Australia		
8800-AU-01C-CBL	Single-Channel Mesh VW Logger, Cable Gland, Australia		
8800-AU-01C-10P	Single-Channel Mesh VW Logger, 10-Pin Bulkhead, Australia		
8800-AU-ADR-CBL	Mesh Addressable Logger, Cable Gland, Australia		
8800-AU-04C-CBL	Four-Channel Mesh VW Logger, Cable Gland, Australia		
8800-AU-08C-CBL	Eight-Channel Mesh VW Logger, Cable Gland, Australia		
8800-AU-TLT-NAP	Mesh Tiltmeter Logger, No Cable Entry, Australia		
8800-PE-SUP-USB	USB Local Gateway, Peru		
8800-PE-SUP-232	RS-232 Local Gateway, Peru		
8800-PE-01C-CBL	Single-Channel Mesh VW Logger, Cable Gland, Peru		
8800-PE-01C-10P	Single-Channel Mesh VW Logger, 10-Pin Bulkhead, Peru		
8800-PE-ADR-CBL	Mesh Addressable Logger, Cable Gland, Peru		
8800-PE-04C-CBL	Four-Channel Mesh VW Logger, Cable Gland, Peru		
8800-PE-08C-CBL	Eight-Channel Mesh VW Logger, Cable Gland, Peru		
8800-PE-TLT-NAP	Mesh Tiltmeter Logger, No Cable Entry, Peru		

TABLE 1: GeoNet 8800 Series Model List

1.3 MESH TILT LOGGER SERIAL NUMBERS

Mesh tilt loggers have two serial numbers: one for the device as a whole, and one for the internal tiltmeter. The device serial number label is below the model number label; the internal tiltmeter serial number is below the calibration date label. See the figure below.



FIGURE 1: Mesh Tilt Logger Serial Number Placement

2. NETWORK COMPONENTS

2.1 CELLULAR GATEWAY

Cellular Gateway models send their data to GEOKON's safe and secure Cloud via a cellular data connection, and are available with LTM or 3G connections.

The cellular connectivity is included in the data plan and no user configuration is necessary. Users can commission or decommission their own systems via GEOKON's online portal.

The gateway stores battery and temperature data sent from the loggers, and data from the sensors, but it does not possess sensor-reading functionality on its own.



FIGURE 2: 880X-XX-XXX-USB

2.2 LOCAL GATEWAY

Local Gateway models lack an integrated cellular module, but they are otherwise functionally the same as Cellular Gateway models.

2.2.1 RS-232 (880X-XX-SUP-232)

This model features an RS-232 connector, for transferring data using an RS-232 cable to a PC running Agent software.



FIGURE 3: RS-232 Local Gateway (8800-XX-SUP-232)

2.2.2 USB (880X-XX-SUP-USB)

This model features a USB connector, for transferring data using a USB cable to a PC running Agent software.



FIGURE 4: USB Local Gateway (8800-XX-SUP-USB)

2.3 SINGLE-CHANNEL LOGGER

A single-channel logger will read one GEOKON vibrating wire gauge, either via 10-pin cable or via a cable with stripped conductor wires, depending on model.

Though designed to send data wirelessly to a gateway, this model also features a USB connector, for transferring data using a USB cable to a PC running Agent software.

2.3.1 10-PIN CONNECTOR (880X-XX-01C-10P)

For use with gauges with 10-pin cable connectors.



FIGURE 5: 10-Pin Single Channel Logger (8800-XX-01C-10P)

2.3.2 GLAND SEAL (880X-XX-01C-CBL)

For use with gauge cables that have stripped conductor wires. The gauge cable passes through an external cable gland and is wired into the terminal block.



FIGURE 6: Gland-Seal Single Channel Logger (8800-XX-01C-CBL)

2.4 MULTIPLE-CHANNEL LOGGERS

Multiple-channel loggers will read up to eight GEOKON vibrating wire gauges, depending on model, via cables with stripped conductor wires. The cables pass through external cable glands and are wired into the terminal blocks.

Multiple-channel loggers function in the same manner as other loggers.

Though designed to send data wirelessly to a gateway, these models also feature a USB connector for transferring data using a USB cable to a PC running Agent software, just as with single-channel loggers.

2.4.1 SINGLE-CHANNEL (8800-XX-ADR-CBL)

For use with sensor cables with stripped and tinned ends. The sensor cable passes through an external cable gland and is wired into the terminal block.



FIGURE 7: Mesh Addressable Logger (8800-XX-ADR-CBL)

2.4.2 FOUR-CHANNEL (880X-XX-04C-CBL)



FIGURE 8: Four-Channel Logger (880X-XX-04C-CBL)

Note: When inserting stripped conductor wires into the terminal blocks, be sure to connect them to the VW terminal blocks.

A four-channel logger can be configured as follows:

Model	Maximum Number of Gauges	Maximum Number of Load Cells
880X-XX-04C-CBL	Four	One 3-gauge or one 4-gauge load cell

TABLE 2: Four-Channel Logger Gauge/Load Limits

2.4.3 EIGHT-CHANNEL (880X-XX-08C-CBL)



FIGURE 9: Eight-Channel Logger (880X-XX-08C-CBL)

Note: When inserting stripped conductor wires into the terminal blocks, be sure to connect them to the VW terminal blocks.

An eight-channel logger can be configured as follows:

Model	Maximum Number of Gauges	Maximum Number of Load Cells
880X-XX-08C-CBL	Eight	One 3-gauge and one 4-gauge load cell
		Two 3-gauge or two 4-gauge load cells
		One 6-gauge load cell

TABLE 3: Eight-Channel Logger Gauge/Load Limits

2.4.4 ADDITIONAL INFORMATION

Addressable loggers are protected from environmental contaminants by a rugged IP66 die cast aluminum enclosure. An earth ground terminal is provided on the exterior of the enclosure to protect against lightning and other large, transient voltages.

2.5 MESH TILT LOGGER (880X-XX-TLT-NAP)

Tiltmeters are designed for permanent long-term monitoring of changes in tilt of structures such as dams, embankments, foundation walls, retaining walls, buildings, and the like.

GEOKON biaxial tiltmeter loggers contain an integrated tiltmeter sensor, and communicate with the gateway in the same manner as other loggers.

The two axes of the tiltmeter have a range of $\pm 90^{\circ}$, based on a starting position of 0°. To achieve the best linearity, mount the tiltmeter so the back of the enclosure is as close as possible to vertical, and the bottom of the enclosure is as close as possible to horizontal.

Though designed to send data wirelessly to a gateway, this model also features a USB connector for transferring data using a USB cable to a PC running Agent software, the same as with the single-channel loggers.



FIGURE 10: Mesh Tilt Logger (880X-XX-TLT-NAP)

2.6 ACCESSORIES

Gateways and loggers are shipped with the following accessories:

- One omni-directional antenna (2.1 dBi). For other antenna options, please contact GEOKON technical support.
- Two D cell alkaline batteries
- Four desiccant packs

Gateways are shipped with the following additional accessories:

- Set of two screwdrivers, one Phillips head and one flat-head
- One RS-232 or USB cable (depending on the model purchased)
- USB to RS-232 adapter cable (RS-232 models only)

2.7 COMPATIBILITY WITH LEGACY GEONET PRODUCTS

8800-XX-XXX-XXX models are compatible with the following legacy GeoNet products:

Legacy Part Number	er New Part Number		
8800-4-1A	8800-NA-SUP-232		
	RS-232 GeoNet Local Gateway, North America		
8800-4-2A	8800-NA-SUP-USB		
	USB GeoNet Local Gateway, North America		
8800-3-1A	8800-NA-01C-CBL		
	Single Channel VW GeoNet Logger, Cable Gland, North America		
8800-3-2A	8800-NA-01C-10P		
	Single Channel VW GeoNet Logger, 10-Pin Bulkhead, North America		
8800-6-1A	8800-NA-ADR-CBL		
	Addressable GeoNet Logger, Cable Gland, North America		
8800-4-1B	8800-BZ-SUP-232		
	RS-232 GeoNet Local Gateway, Brazil		
8800-4-2B	8800-BZ-SUP-USB		
	USB GeoNet Local Gateway, Brazil		
8800-3-1B	8800-BZ-01C-CBL		
	Single Channel VW GeoNet Logger, Cable Gland, Brazil		
8800-3-2B	8800-BZ-01C-10P		
	Single Channel VW GeoNet Logger, 10-Pin Bulkhead, Brazil		
8800-6-1B	8800-BZ-ADR-CBL		
	Addressable GeoNet Logger, Cable Gland, Brazil		
8800-4-1C	8800-AU-SUP-232		
	RS-232 GeoNet Local Gateway, Australia		
8800-4-2C	8800-AU-SUP-USB		
	USB GeoNet Local Gateway, Australia		
8800-3-1C	8800-AU-01C-CBL		
	Single Channel VW GeoNet Logger, Cable Gland, Australia		
8800-3-2C	8800-AU-01C-10P		
	Single Channel VW GeoNet Logger, 10-Pin Bulkhead, Australia		
8800-6-1C	8800-AU-ADR-CBL		
	Addressable GeoNet Logger, Cable Gland, Australia		

TABLE 4: Legacy Compatibility Chart

2.8 NETWORKS

Many networks use a star topology, where all loggers can send data directly to the gateway. Other networks use a mesh topology, in which loggers will relay data from any logger that might be blocked, or out of range from the gateway.

GeoNet networks are **self-healing**. This means that GeoNet will switch to a mesh topology so that loggers will automatically relay data from troubled loggers to the gateway, if needed.

GeoNet networks are **self-configuring**, meaning that the switch from a star topology to a mesh topology is automatic, and the loggers will determine for themselves which will relay data to the gateway.



FIGURE 11: Star Network Topology



FIGURE 12: Mesh Network Topology

Each transmission from logger to gateway or logger to logger is considered one "hop". Examples of hops are shown in figures above and below. Up to four hops can be made between a logger and the gateway. With the ability to hop comes the ability for the gateway to communicate with loggers that have not established direct radio contact. GeoNet devices can operate around buildings or other barriers using hops.



FIGURE 13: Working Around Obstructions via Hops

FRESNEL ZONE

The Fresnel zone is the geographic area between the sending antenna and the receiving antenna. Objects in the Fresnel zone can cause reflections of the transmitted signal. When these reflections arrive at the receiving antenna, they may be out of phase with the signal that took a straight-line path, and this can weaken the straight-line signal.

For optimum performance, GEOKON recommends creating as much vertical space as possible between the straight-line path and obstacles, including the ground.

The Fresnel zone must be at least 60% obstruction-free to ensure optimal wireless communication. The figure below illustrates the Fresnel zone.



FIGURE 14: Fresnel Zone

IMPORTANT: If communication cannot be established when GeoNet is deployed to a site, it may be necessary to elevate the devices or their antennas, or to move them to a location where a radio link can be established. This may require extending the readout cable of the attached sensors, or adding an antenna cable extension.

3. NETWORK INSTALLATION

A network must include a gateway and at least one logger that is within radio range of the gateway.



before you deploy them to their respective on-site positions. Skipping or omitting steps, or performing them out of order, could

GEOKON recommends that you configure your network with the devices at the same location, in close proximity to each other,

complicate the installation of your network.

An installation tutorial on the GEOKON website, https:// www.geokon.com/tutorial-videos, can help with this.

Install the network using the following steps:

- 1. Configure the Network
 - Prepare the Gateway and Loggers
 - Configure the Gateway
 - Activate the network
- 2. Deploy the network
 - Mount the devices
 - Connect the Loggers to the sensors.
 - Link the Cellular Gateway to the Cloud (if used)

CONFIGURE THE NETWORK

3.1 PREPARE THE GATEWAY AND LOGGERS

3.1.1 INSTALL THE ANTENNAS ON ALL DEVICES

Remove the rubber caps from the antenna mounts. Position the antennas on the mounts and then rotate the antennas in a clockwise direction until tightened.

3.1.2 REMOVE THE COVERS FROM ALL DEVICES

Remove the cover by unscrewing the four captive screws on the front of the enclosure. Ensure that no dirt, water, or other contaminants are allowed to enter the enclosure.

Repeat this for each device.

3.1.3 CONFIGURE THE CHANNEL ON ALL DEVICES

GEOKON configures all devices to use Channel 1; if no other networks operate in the area, then no specific network configuration is needed and you can skip to Section 3.2.

If multiple networks are within radio range of each other, then each network (up to a limit of 12) must be configured to use a different channel. Devices of each network must be set to their respective channel.

SET THE GATEWAY AND LOGGER CHANNEL:

Move the channel select DIP switches (shown in the figure below) to any of the twelve valid positions listed in Table 5 below. The setting will take effect at power-up, or after the device is reset.



FIGURE 15: Channel Select Switches

Channel	1	2	3	4
1	OFF (down)	OFF	OFF	OFF
2	ON (up)	OFF	OFF	OFF
3	OFF	ON	OFF	OFF
4	ON	ON	OFF	OFF
5	OFF	OFF	ON	OFF
6	ON	OFF	ON	OFF
7	OFF	ON	ON	OFF
8	ON	ON	ON	OFF
9	OFF	OFF	OFF	ON
10	ON	OFF	OFF	ON
11	OFF	ON	OFF	ON
12	ON	ON	OFF	ON

TABLE 5: Channel Selection

3.2 CONFIGURE THE GATEWAY

3.2.1 POWER CONCERNS

In a new network, be sure to power the gateway **before** powering the loggers.

When the unit is powered, a green LED on the right side of the box will flash twice after a small delay, indicating the unit has power. The LEDs will not flash again until at least one logger has joined the Network.

Note: Deployment mode starts as soon as devices are powered on or reset. See Section 3.7 for information on Deployment mode.

Note: If replacing batteries in an existing network, ensure that the network is in Deployment Mode prior to removing the batteries. See Section 4.3 for more information on battery replacement.

3.2.2 POWER THE GATEWAY

■ Cellular Gateway 880X-XX-LTM-USB, 8800-XX-03G-USB

Move the battery switch to the 9-24V or BATTERY position, according to the chart below. Connect to external DC power, then proceed to Section 3.2.3.

For solar panel information, see Appendix F.

	Geographic Zone		
Power Source	Temperate	Sub Polar	
Mains or solar with external battery	PATTERV	9-24V	
Solar without external battery	DATIENT	N/A	

TABLE 6	: Cellular	Gateway	/ Ratter	v Switch	Ontions
IADEE 0	. Conulai	Gateway	Dattor	y Ovencon	opuons



FIGURE 16: Cellular Gateway Battery Switch

FIGURE 17: Local Gateway Battery Switch

■ Local Gateway 880X-XX-SUP-232, 880X-XX-SUP-USB

Move the battery select switch to either the ALKALINE or LITHIUM position depending on the type of battery being used.

Align the positive (+) side of the batteries with the + indicator in the battery holder. Push the batteries straight down into the holder.



FIGURE 18: Battery Detail

3.2.3 SEAL THE GATEWAY

- 1. Place the supplied desiccant packs inside the enclosure.
- 2. Ensure the cover gasket and the mating ridge on the enclosure are clean, and that the gasket is properly seated inside the groove on the cover. Place the cover on the unit.

3. Tighten the cover screws slowly. If an electric screwdriver is used, **do not** fully tighten the screws; do the final tightening by hand. Work in a diagonal pattern.

Important! Make sure the cover seals tightly and evenly.

3.2.4 SET THE NETWORK TIME

A Cellular Gateway will set the network time automatically when it connects to the cellular network. A Local Gateway must have its time set manually using GEOKON's "Agent" data collection software.

Connect the Local Gateway to the computer using the GEOKON-supplied USB cable. For RS-232 models, connect the USB cable using the GEOKON-supplied RS-232 adapter.

Note: For details on setting up a Network in Agent, watch the Agent software tutorial or refer to the Agent instruction manual. The network will not begin collecting data until the network time is set.

3.2.5 VERIFY THE NETWORK TIME

Press the Status button to verify that the network time is set. The LEDs should flash both green and red. If only the red LED flashes:

- For a Cellular Gateway, wait several minutes and try again.
- For Local Gateway, set the network time using Agent.

3.2.6 RECORD THE GATEWAY SERIAL NUMBER

The serial number of the gateway is required when using Agent software and when commissioning the gateway.

3.3 ACTIVATE THE NETWORK

3.3.1 POWER THE LOGGERS

Power the loggers in a manner similar to the process of powering the gateway. Do the following:

- 1. Move the battery select switch to either the ALKALINE or LITHIUM position depending on the type of battery being used.
- 2. Align the positive (+) side of batteries with the + indicator in the battery holder. Push the batteries down into the holder.

An LED will flash twice, indicating the unit has power.

3.3.2 VERIFY THE NETWORK CONNECTION OF THE LOGGERS

If the gateway is in Deployment mode, the loggers will join the network about 30 seconds after power up, as indicated by the LED(s) on the loggers flashing in unison with the gateway.

Verify that the LED indicators on the loggers and the gateway are flashing green only. This may take several minutes depending on network configuration.

DEPLOY THE NETWORK

3.4 MOUNTING THE DEVICES

The attached mounting bracket is designed to be used with U-bolts, hose clamps, screws, etc. Mount all devices vertically, with the antenna pointing up.

GEOKON recommends a mounting height of at least two meters. Lower than two meters may compromise performance; as a rule, higher is usually better.

3.4.1 MOUNTING LOCATION CONSIDERATIONS

Select the mounting location with care. Certain mounting configurations can hinder or even completely block wireless signal transmission, or can introduce electrical noise to the signal.



Common mounting mistakes include the following:

FIGURE 19: Installing Near a Large Object



FIGURE 20: Installing Close to Buildings or Fences/Walls, and/or Horizontally



FIGURE 21: Mounting onto a Metal Plate and/or Inside an Enclosure

Large structures, such as walls, buildings, hills, etc. can block and/or reflect RF signals. Tips include:

- Mount antennas above metallic structures.
- Keep in mind that loggers communicate with each other, not just with the gateway.
- A high Received Signal Strength Indicator (RSSI) level does not guarantee trouble-free communication.
- Mount devices such that their antennas are on top, pointing upward.

3.4.2 GROUND THE GATEWAY AND LOGGERS

Install a grounding rod and cable, or other suitable ground, at a location near each device. Cellular Gateways and multiple-channel loggers come equipped with a copper grounding lug to which you can connect the grounding cable. Ground Local Gateways and loggers by connecting the grounding cable to the mounting bracket.

3.5 CONNECT THE SENSORS TO LOGGERS

3.5.1 MAKING CABLE GLAND CONNECTIONS

To connect a device using a cable gland connection:

- 1. Loosen the nut on the cable fitting and remove the white plastic dowel.
- 2. Slide the transducer cable through the cable gland nut and fitting.
- Insert the lead wires into the terminal block as shown in Figure 22 and Table 7. Press down on the orange tab, insert the bare end of the wire into the terminal block, and then release the tab.
- 4. Pull gently on each conductor to ensure it is secure.
- Tighten the cable gland nut until it firmly grips the outer jacket of the cable. The cable gland nut must be properly tightened to prevent water entry. Do not over-tighten, as this might strip the plastic threads.
- 6. Pull gently on the gauge cable to ensure it is held in place by the cable gland.
- 7. Repeat these steps for each gauge cable to be connected.



FIGURE 22: Terminal Connections

To prevent a short circuit, do not allow bare leads to touch each other during or after wiring.

R	S-485 (Mesh	Addressable Logger)	Singl	e/Multiple-C	hannel Mesh VW Logger
Position	Color	Description	Position	Color	Description
485+	WHITE	RS-485 Data +	VW+	RED	Vibrating Wire +
485–	GREEN	RS-485 Data –	VW-	BLACK	Vibrating Wire –
12V	RED	12 Volt Bus	TH+	WHITE	Thermistor +
GND	BLACK	Bus Ground	TH-	GREEN	Thermistor –
SHD	BARE	Analog Ground (shield)	SHD	BARE	Analog Ground (shield)

TABLE 7: Logger Wiring

3.5.2 MAKING 10-PIN CABLE CONNECTIONS

To connect a device using a 10-pin connection:

- 1. Remove the cover from the 10-pin connector.
- 2. Align the grooves on the sensor connector (male), with the connector on the logger (female).
- 3. Push the connector into place and then twist the outer ring of the male connector until it locks.

3.5.3 NOTES ABOUT MULTIPLE-CHANNEL AND ADDRESSABLE LOGGERS

- For ease of wiring, sensor cables should be inserted into the cable glands on multiple-channel loggers from left to right.
- Sensors should be wired into the channels of a logger in sequence starting with Channel 1.
- Do not wire sensors into the terminal blocks marked '485 IN' and '485 OUT' on a multiple-channel logger.
- Multiple-channel loggers and addressable loggers stop trying to read an empty channel after two attempts. The logger will read all channels at the top of every hour; it will resume sampling when it detects a sensor.

3.5.4 SEAL THE LOGGERS

Seal the loggers using the instructions in Section 3.2.3.

Important! Make sure the cover seals tightly and evenly.

WARNING: Single-channel enclosure lids are square but not symmetrical. They must be oriented correctly; attempting to seal a misaligned lid could strip the threads and/or allow moisture to enter the enclosure.

3.5.5 RECORD LOGGER AND SENSOR SERIAL NUMBERS

Record the serial numbers of both the loggers and of the attached sensors.

For multiple-channel loggers, also record the channel to which each sensor has been connected.

The serial numbers are required when using Agent software and when commissioning the Cellular Gateway.

3.6 CELLULAR GATEWAY COMMISSIONING

Commissioning allows the Cellular Gateway to account for all of the loggers in the network. For ease of setup, make sure all loggers have been added to the network before commissioning the gateway.

Note: The Cellular Gateway cannot account for loggers added to the network after the commissioning process has been completed. Run the commissioning process again when adding new loggers.

To commission the Cellular Gateway, do the following:

\leftarrow	\rightarrow	Ö	ŵ	A https://api.geokon.com/	∱≡	h	È	
	G	EO	КО		А	PI D	ocs	
				[
				A Email				
				🗄 Password 🖉				
				Remember me Forgot Password				
				Log in				
				Or create user				
				Or use API without login				
				Geokon ©2020				

1. Display https://api.geokon.com in a Web browser.

FIGURE 23: Accessing the Cloud

2. Click "create user".

Note: To access your data using an API, click "use API without login".

3. Enter your credentials and read/agree to the terms of service.

Create User		×
* E-mail:	sample@geokon.com	
* Password:		Ø 🔮
* Confirm Password:		Ø 🔮
* Name ②:	John Doe	
	✓ I agree to the terms of	service
		Cancel Submit

FIGURE 24: Create a User

- 4. Click Submit.
- 5. Log in using your email address and password.
- 6. Click "Add account".

GEOKON TRUSTED MEASUREMENTS:	Select an account V 💿 🕸 🕒
🙏 Devices	
a ^g Connections	
E Billing	
	No account data
Ē	Add acount

FIGURE 25: Add an Account

7. Click "create new account".

GEOKON TRUST		Select an account	× 0	
"å, Devices				
a ^g Connections	A User	象 API Accounts		
🖬 Billing	Add Acc	counts		
	* /	Account Token ⑦:		
Ē		Ad Or cr	ld account eate new accou	nt

FIGURE 26: API Accounts

8. Enter your credentials and credit card information, then click Submit. A copy of the account token will be emailed to the address associated with the account as a receipt.

Create Account	×
* E-mail:	sample@geokon.com
* Name ⑦:	John Doe
* Phone Number:	6034481562
* Credit Card :	Card number MM/YY CVC
	Cancel Submit

FIGURE 27: Enter your Credentials

9. Click Devices, then enter the serial number of the Cellular Gateway.

GEOKON	TRUS	TED MENTS:				V Grand	000
a, Devices							
ø Connections		Logger	s				Register Device
Billing		Name 💠	Status	Network Type 💠	Data Type 💲	Last Connect 🝦	Last Data 💠
	+	0000000	Disconnected	Mesh Gateway	None	4/2/2021, 8:51 AM	4/2/2021, 8:50 AM
							< 1 >
Ē							

FIGURE 28: Enter the Serial Number

- 10. Click Register Device.
- 11. Click the button next to Activate Cellular Service to activate the Cellular Gateway.

	JSTED UREMENTS	v 🕲 🕲 😋
& Devices		
ø ^g Connections	C 0000000	Active
Billing	Serial: 0000000	
	Logger Configuration	
	Read Interval: 10 Minutes	
	Power Mode 🕥: Normal	
	Update Logger	
	Cellular Configuration	
↓	Activate Cellular Service:	

FIGURE 29: Activate Cellular Service

- 12. Add logger(s) to the gateway by clicking the + sign next to the Cellular Gateway name. Populate the fields that display.
- 13. Add sensors to the logger(s) by clicking the + sign next to a logger, then enter the serial number(s) of the sensor(s) attached to the logger, one per channel.

Ø Battery Voli 3.1 V	tage	Temperature 24.6 °C	((;-	Mesh Signal	Diagnostic Observation: 1,342
Sensor Cha	nnels				
Channel	Serial		Sensor Type	Observations \ddagger	Last Data 👙
1	enter serial #			96	5/13/2021, 7:40 AM
2	enter serial #			0	Never
3	enter serial #			0	Never
4	enter serial #			0	Never
8	enter serial #			6308	12/2/2020, 7:30 PM

FIGURE 30: Enter Sensor Serial Numbers

14. Click Update Info to save the sensor configuration.

	> Properties		
Name:	00000		
Notes:			

FIGURE 31: Update the Sensor Configuration

- 15. Repeat steps 12 14 for all loggers on the Network.
- 16. Click Connections, then enter a token name in the Create Token field.
- 17. Click Create Token. A new token entry displays.
- 18. Click the blue token to copy it to the Windows Clipboard.

	EMENTS:			~ (® C
å Devices					
ø ^g Connections	API Tol	kens		Token name C	eate Token
Billing	Name 💠	Token 🔶	Created \Leftrightarrow	Last Access 👙	
	Geokon Token	p9hoTm68YI7pmWsdgDE4NQ==	8/12/2020, 3:11:17 PM	8/13/2020, 9:28:00 AM	•
Ē					

FIGURE 32: Copy the Token

19. Paste the token into GEOKON's data collection software, "Agent", to commission the Cellular Gateway and retrieve data.

3.7 DEPLOYMENT MODE

There are two modes of operation: Deployment mode and Normal mode. Deployment mode allows loggers to be quickly added to a network and verified.

Put the gateway into Deployment mode before making any changes, such as adding loggers (during initial setup or later), resetting loggers, or resetting the gateway.

The gateway enters Deployment mode upon power up, pressing the Status button, or system reset.

- To start Deployment mode, press and release the Status button on the gateway.
- To reset the system, press and hold the Status button for 10 seconds.



CAUTION! DO NOT reset the gateway unless it is in Deployment mode.

For information on the function of the Status button, see Section 3.8.

When the network is in Deployment mode, the network status will be indicated by the LEDs on the gateway approximately every 10-15 seconds.

Under normal Deployment mode radio conditions, the gateway and logger units will find each other in less than three minutes; this establishes the network.

Once the network is established and the network time is set, the gateway's green LED will flash simultaneously with the green LEDs on the loggers. If the network time has not been set, the gateway's red LED will blink in unison with the loggers. In that case the time must then be set using the Agent software.

IMPORTANT: Deployment mode will cease automatically after one hour, at which time Normal mode will being.

If the correct lights do not illuminate, or if the network has exited Deployment mode, press the Status button on the gateway to restart Deployment mode.

3.7.1 PLACING THE GATEWAY AND ADDING LOGGERS

Place the gateway in a location central to the distribution of the loggers, if possible (see Figure 33 below). Doing so will minimize the number of hops, which will improve battery life.

While in Deployment mode, loggers may be added simply by turning them on within radio range. When adding loggers, **start with those closest to the gateway**.

Watch the LEDs while moving the loggers, to ensure the signal isn't lost.

After 10 minutes, the LEDs on the loggers will stop indicating their status, to conserve batteries. Pressing the Status button on a logger will reactivate the LEDs for another 10 minutes.

By default, a network will remain in Deployment mode for one hour. When a new logger joins the network the timer will reset, extending the deployment period for another hour. If more time is needed while deploying loggers, the default deployment timeout may be changed using Agent software.

If isolated from the rest of the network, a logger will continue to sample and store data. When communication is reestablished, it will "catch up" by sending all collected data to the gateway.



For networks with a Local Gateway, data will not be collected until the network time is set. To do this, use the Agent software. The default scan interval for data collection is 10 minutes.



FIGURE 33: Installation Sequence

3.8 STATUS BUTTON FUNCTIONALITY

All GeoNet devices have red and green LED indicators to display their status. A reference key is printed on the side of each unit, below the LEDs. When pressed, the Status button triggers the appropriate LED indicators to briefly illuminate.

The table below shows the meaning of the various LED indications.

LE	Ds	Gateway	Loggers	
Green		Time set, Loggers present	GOOD: Radio signal > 30%	
Green	Red	Time set, no Loggers present	MARGINAL: Radio signal < 30%	
	Red	Network time not set	BAD: No radio signal	

TABLE 8: LED Indicator Meaning

When the Status button is pressed on the gateway, the LEDs briefly display the network status. If the network is in Deployment mode when the button is pressed, the Deployment mode timer will reset. If the network is not in Deployment mode, it will enter Deployment mode on the following radio cycle. This could take up to six minutes, as changes to the radio settings can only occur when all the radios in the network are awake. In order to provide timely feedback to the user, the network parameters are set to a 10-second radio interval while the gateway is in Deployment mode.

When the Status button is pressed on a logger, the LEDs briefly display the radio signal status. The logger will indicate the status of the radio signal after each radio transmission for a period of 10 minutes. If a logger has not yet joined the network, it will change its radio interval to approximately one second and search for an available network.

Device	Function	Status Button Action
Gateway or Logger	Reset	Press and hold until both LEDs illuminate (~10 seconds)
Gateway	Put the network into Deployment mode/extend Deployment mode. Display the current status.	Press and release
Gateway	Take a reading and send existing data immediately	Press and release
Logger	Display the current status, then indicate signal strength every radio cycle for 10 minutes	Press and release

TABLE 9: Status Button Functions

4. MAINTENANCE

All GeoNet devices are designed to operate in field environments with minimal upkeep; nevertheless, there are some basic maintenance procedures that should be followed to ensure maximum reliability and functionality.

4.1 PREVENTING WATER FROM ENTERING THE ENCLOSURES

GeoNet devices are designed to be splash proof and rain proof, but are not submersible.



These units are sealed by a gasket preventing water entry, so long as the screws that hold the lid in place are properly tightened and the gasket inside the lid is properly aligned. It is also very important to ensure that all the cable fittings are securely tightened. Models that feature a 10-pin connector are equipped with a watertight cap, which must be installed when the connector is not in use.

Despite these precautions, the loggers may encounter leakage along the cable if the cable is cut, or if the unit is installed in an especially humid environment. In this type of environment, GEOKON recommends that the internal desiccant packs be replaced at intervals to prevent condensation from corroding or shorting out the internal electronics.

4.2 BATTERY LIFE

Battery life is affected by the quantity and physical configuration of the loggers, along with weather conditions and the radio environment (as related to retries).

Loggers that are the only communication link between other loggers and the gateway will have a shorter battery life than those that have no routing responsibility.

Table 10 below shows an estimate of battery life in a network of fewer than 20 loggers based on the number of readings collected and forwarded to the gateway. More than 1,000 days of battery life are possible when using a scan rate of one hour or higher, with only one hop. A more frequent scan rate will reduce this estimate. If greater battery life is needed, a 12-volt nominal input is available from GEOKON.

	Alkaline	Lithium
Readings Transmitted	25,000	70,000
Radio Cycles	500,000	1,400,000
Scan Rates (minutes)	Days	Days
12	208	583
20	347	972
30	521	1458
60	1042	2915

TABLE 10: Battery Life Estimates

4.3 REPLACING BATTERIES

The network must be put into deployment mode prior to replacing the batteries in the gateway. This is also best practice when replacing batteries in loggers.

Replace D cell batteries when their measured voltage drops below 2.0 VDC. Replace external 12-volt batteries when the measured voltage drops below 11 VDC. All data is retained in nonvolatile flash memory. Data will not be lost even if the batteries are removed for an extended period (e.g., years).

REPLACE THE BATTERIES AS FOLLOWS:

- Place the network in deployment mode by pressing the status button on the gateway. Within six minutes the green LED will begin flashing every 10 seconds.
- 2. Open the logger by unscrewing the four captive screws on the front of the enclosure. Make sure that no dirt, water or other contaminants are allowed to enter the enclosure.
- 3. Set the battery select switch to the OFF (middle) position.
- 4. Remove the existing batteries, if installed.
- Install the batteries by aligning the positive (+) side of the D cells with the (+) indicator in the battery holder. Push the batteries straight down into the holder.
- 6. Move the battery select switch to either the Alkaline or Lithium position depending on the type of battery being used. An LED will flash on the right side of the box indicating the unit has power. Once the logger reconnects to the network, the green LED will blink every 10 seconds in unison with the LED on the gateway.

Note: If replacing the batteries in a network gateway and power is restored promptly, the gateway will remain active. If power is not restored promptly the network time will be lost and must be reset using the Agent software. The loggers within the network will reconnect automatically.

4.4 LIGHTNING PROTECTION

Each vibrating wire (VW) channel is protected by a 230V gas discharge tube, followed by a high-speed surge protector and a transient voltage suppression diode. Each thermistor (TH) channel is protected by a 230V gas discharge tube, followed by an inductor (lower resistance than high-speed surge protectors) and a transient voltage suppression diode.

For these components to safely divert lightning energy to ground, a solid electrical connection to earth ground is required. A copper grounding rod at least six feet in length should be driven into the soil to a minimum depth of three feet, as close to the device as possible. Alternatively, any other suitable earth ground attachment may be used. Connect the grounding rod to the copper grounding lug on the exterior of the device (if equipped) with a 12 AWG or larger wire. This will provide a path from the device to earth ground in the event of a lightning strike.

5. MODEL 8800-2-4B ADD-ON MODULE

5.1 INTRODUCTION

Model 8800-2-4B (Ethernet compatibility) is an add-on module for the gateway to allow the end user to easily add remote communications and data download functionality.

Each module comprises a weather proof enclosure $305 \times 254 \times 152$ mm (12" x 10" × 6") in size, a 7 amp hour rechargeable battery, a charger, and the necessary cables to interface with a GeoNet gateway.

When an add-on module is paired with a gateway, the gateway is powered by the rechargeable battery inside the module. The charge level of the battery can be monitored using the Agent software.

5.2 INSTALLATION OVERVIEW

Modules are shipped with the batteries uninstalled and the fuse distribution board switch in the OFF position. To deploy modules, install the batteries and set the switch to the ON position. Use the provided black 10-pin to 10-pin connecting cable to connect the module to the gateway.

Install D cell batteries in the gateway and set the battery switch to the appropriate setting to ensure communication between the gateway and the loggers will not be interrupted if the battery level drops. See Section 3.2.1.

5.3 IP ADDRESS CONFIGURATION

GEOKON sets the module to communicate with a GeoNet gateway; however, the user must finish the setup so that it works with their network. Configure an IP address by following the instructions below.

Note: The following steps should only be performed by your network administrator. NPort Administrator (on CD) should be installed and used to configure the required IP changes.

- 1. Connect a computer to the module via the Ethernet Port.
- 2. Open NPort Administrator and click *Search*. (By default, the MOXA 5110A IP Address 192.168.127.254 will be displayed.)
- 3. Double-click on the *IP Address* under the configuration window.
- 4. In the configuration window, click on the Network tab.
- 5. Check the boxes next to Modify IP address and Modify Netmask.

nfiguration	A 7 A			
Information Model Name	Accessible IPs	Auto Warning	IP Address Re	eport Password
NPort 5110	Dasic		Jenar	operating mode
MAC Address 00:90:E8:48:C4:8A	IP Address	192.168.1	27.254	
Serial Number	Modify			
3121	Netmask	255.255.25	2.0	
	Gateway			
Firmware Version	IP Configuration	Static	•	
Ver 2.4	DNS Server 1			
System Uptime	DNS Server 2			

FIGURE 34: Nport Configuration

6. Update the *IP Address*, *Netmask*, *Gateway*, and *DNS Server 1* fields to match your network.

Note: Do not make any other changes to the settings because it may hinder proper communications with the gateway.

1	NPort Administrator-Configuration	on					X
E	ile <u>Function Configuration View</u>	Help				X]-
	Information Model Name NPort 5110	Accessible IPs Basic	Auto Warning Network	IP Address Serial	Report Oper	Password ating Mode	tus
	MAC Address 00:90:E8:48:C4:8A	Modify IP Address	192.168.1	127.254	ן		
	Serial Number 3121	V Modify Netmask	255.255.25	52.0			
	Firmware Version Ver 2.4	Gateway IP Configuration DNS Server 1	Static	•	•		
System Uptime 0 days, 00h:03m:44s		DNS Server 2					
		Modify	Enable SNI	MP			

FIGURE 35: Update Fields

- 7. Click OK.
- 8. Use the ON/OFF switch to restart the module.
- 9. Connect the add-on Module to the gateway.
- 10. Enter the new IP address followed by **:4001** in the *Network Address* field in Agent software.

AGENT»	0
projects S	Sample Project
list	Network Settings Name Network Address
add network	MOXA 5110A Network XXX.XXX.XXX.4001 get network settings
transfer settings	Serial Number Scan Rate Deploy Period

FIGURE 36: Enter the IP address followed by :4001

For more information on using Agent software, please refer to the Agent Software Program instruction manual, available at https://www.geokon.com.

APPENDIX A. SPECIFICATIONS

A.1 GATEWAY SPECIFICATIONS

Data Memory	32 MB
Storage Capacity	> 1.04 M Arrays
Communication Type	USB, RS-232
Communication Speed	115.2 kBits/second
Communication Parameters	8,N,1 (data bits, parity, stop bits)
Scan Interval	10-1440 Minutes
USB Driver	FTDI
Power Supply	Cellular Gateway: Battery pack, or 9-24V DC external Local Gateway: D cell, alkaline or lithium (2x), or 12V external
Operating Time	Please contact GEOKON
Operating Temperature	–40 °C to +85 °C
(L×W×H)	Cellular Gateway: 160 × 260 × 91 mm Local Gateway: 120 × 122 × 91 mm

TABLE 11: Gateway Specifications

A.2 LOGGER SPECIFICATIONS

Data Memory	32 MB
Storage Capacity	Varies by model
Trueness	0.082 Hz
Frequency Precision	±0.146Hz (99% CI)
Frequency Resolution	±0.002 Hz
Thermistor Accuracy	External thermistor: ±0.5 °C On-board sensor: ±0.4 °C
Thermistor Resolution	External thermistor: ±0.032 °C On-board sensor: ±0.1 °C
Scan Interval	10-1440 Minutes
Power Supply	D cell, Alkaline or Lithium (2x), or 12V external
Operating Temperature	-40 °C to +85 °C
VW Excitation Peak Current	25 mA (max)
VW Frequency Range	400 Hz - 5000 Hz
Sweep/Read Duration/Channel	< 500 mS
Battery Life	Refer to Section 4.2
Dimensions (L×W×H)	120 × 122 × 91 mm (single-channel) 160 × 260 × 91 mm (four-channel) 180 × 280 × 101 mm (eight-channel)
Vibrating Wire Channel Lightning Protection	Gas discharge tube High-speed surge protector Transient voltage suppression diode
Thermistor Channel	Gas discharge tube Inductor (lower resistance than high-speed surge protectors) Transient voltage suppression diode

TABLE 12: Logger Specifications

A.3 NETWORK SPECIFICATIONS

Network	North America	Brazil	Australia		
Radio Frequency, ISM Band	902-928 MHz	902-906, 915-928 MHz	915-928 MHz		
Topology	Star/Mesh/Cluster Tree (Automatic)				
Radio Technology	FHSS				
Channels	12				
Range ¹	1.22 km (305 km x 4 hops) 26 km (6.5 km x 4 hops)				
Transmit Power	250 W				
Receiver Sensitivity	-101 dBm				
Antenna (Half-Wave Dipole)	2.1 dBi				

¹Line-of-sight, maximum 4 hops

TABLE 13: Network Specifications

A.4 MESH TILT LOGGER SPECIFICATIONS

Precision	±26.9 [0.0075°]	Arcseconds [Degrees]
Nonlinearity	$\pm 0.005^{\circ}$ across $\pm 30^{\circ}$ range (0.09 mm/m)	Arcseconds [Degrees]
Temperature-Dependent Uncertainty	68.8 [0.019°]	Arcseconds [Degrees] / °C
Angle Resolution	0.9 [0.00025°]	Arcseconds [Degrees]
Tilt Range	±90°	Degrees
Axes	2	

TABLE 14: Mesh Tilt Logger Specifications

APPENDIX B. CONNECTOR PINOUTS

B.1 GAUGE CABLE

B.1.1 GLAND SEAL MESH VW LOGGERS (880X-XX-01C-CBL)

Terminal Strip Position	Description	Cable Wire Color
VW+	Vibrating Wire+	RED
VW–	Vibrating Wire-	BLACK
TH+	Thermistor+	WHITE
TH-	Thermistor-	GREEN
S	Analog Ground (shield)	BARE WIRE

TABLE 15: Mesh VW Logger Cable Connections (Gland Seal)

B.1.2 10-PIN BULKHEAD MESH VW LOGGERS (880X-XX-01C-10P)

10-Pin Bulkhead	Internal Wire Color	Description	Cable Wire Color	
A	Brown	Vibrating Wire+	RED	
В	Red	Vibrating Wire-	BLACK	
С	Orange	Thermistor+	WHITE	
D	Yellow	Thermistor-	GREEN	
E	Green	Analog Ground (shield)	BARE WIRE	
F	Blue	+VCC Supply	N/A	
G	Violet	Digital Ground	N/A	
Н	Grey	Mux Reset	N/A	
J	White	Mux Clock	N/A	
К	Black	Digital Ground	N/A	

TABLE 16: Mesh VW Logger Cable Connections (10-Pin Bulkhead)

B.1.3 MESH ADDRESSABLE LOGGERS (880X-XX-ADR-CBL)

Terminal Strip Position	Description	Cable Wire Color
485+	RS-485 Data+	WHITE
485-	RS-485 Data-	GREEN
12V	12 Volt Bus	RED
GND	Bus Ground	BLACK
S	Analog Ground (shield)	BARE WIRE

TABLE 17: Mesh Addressable Logger Cable Connections (Gland Seal)

B.2 COMMUNICATION CONNECTIONS

B.2.1 RS-232 (880X-XX-SUP-232)

10-Pin Bulkhead	Internal Wire Color	Description	Connection	
٨	Brown	CND	J1-1	
A	Green	UND	J1-5	
В	Red	RX	J1-2	
С	Yellow	TX	J1-4	
J	Bed and Black (twisted nair)	12V Aux In (Red)	J3-1	
К	nou una black (twistou puil)	GND (Black)	J3-2	

TABLE 18: Communication Connections (RS-232)

B.2.2 USB (880X-XX-SUP-USB)

10-Pin Bulkhead	Internal Wire Color	Description	J9	
А	Red	+5V	2	
В	Orange	D-	3	
С	Yellow	D+	4	
D	Brown	CND	1	
D	Green	עאט	5	

TABLE 19: Communications Connections (USB)

APPENDIX C. THERMISTOR TEMPERATURE DERIVATION

3KΩ THERMISTOR RESISTANCE

Thermistor Types:

- YSI 44005, Dale #1C3001–B3, Alpha #13A3001–B3
- Honeywell 192–302LET–A01

Resistance to Temperature Equation:

 $T = \frac{1}{A + B(LnR) + C(LnR^3)} - 273.15$

EQUATION 1: 3kΩ Thermistor Resistance

Where:

$$\label{eq:transform} \begin{split} T &= \text{Temperature in °C} \\ \text{LnR} &= \text{Natural Log of Thermistor Resistance} \\ A &= 1.4051 \times 10^{-3} \\ B &= 2.369 \times 10^{-4} \\ C &= 1.019 \times 10^{-7} \end{split}$$

Note: Coefficients calculated over the -50 to +150 °C span.

Ohms	Temp	Ohms	Temp	Ohms	Temp	Ohms	Temp	Ohms	Temp
201.1K	-50	15.72K	-9	2221	32	474.7	73	137.2	114
187.3K	-49	14.90K	-8	2130	33	459.0	74	133.6	115
174.5K	-48	14.12K	-7	2042	34	444.0	75	130.0	116
162.7K	-47	13.39K	-6	1959	35	429.5	76	126.5	117
151.7K	-46	12.70K	-5	1880	36	415.6	77	123.2	118
141.6K	-45	12.05K	-4	1805	37	402.2	78	119.9	119
132.2K	-44	11.44K	-3	1733	38	389.3	79	116.8	120
123.5K	-43	10.86K	-2	1664	39	376.9	80	113.8	121
115.4K	-42	10.31K	-1	1598	40	364.9	81	110.8	122
107.9K	-41	9796	0	1535	41	353.4	82	107.9	123
101.0K	-40	9310	1	1475	42	342.2	83	105.2	124
94.48K	-39	8851	2	1418	43	331.5	84	102.5	125
88.46K	-38	8417	3	1363	44	321.2	85	99.9	126
82.87K	-37	8006	4	1310	45	311.3	86	97.3	127
77.66K	-36	7618	5	1260	46	301.7	87	94.9	128
72.81K	-35	7252	6	1212	47	292.4	88	92.5	129
68.30K	-34	6905	7	1167	48	283.5	89	90.2	130
64.09K	-33	6576	8	1123	49	274.9	90	87.9	131
60.17K	-32	6265	9	1081	50	266.6	91	85.7	132
56.51K	-31	5971	10	1040	51	258.6	92	83.6	133
53.10K	-30	5692	11	1002	52	250.9	93	81.6	134
49.91K	-29	5427	12	965.0	53	243.4	94	79.6	135
46.94K	-28	5177	13	929.6	54	236.2	95	77.6	136
44.16K	-27	4939	14	895.8	55	229.3	96	75.8	137
41.56K	-26	4714	15	863.3	56	222.6	97	73.9	138
39.13K	-25	4500	16	832.2	57	216.1	98	72.2	139
36.86K	-24	4297	17	802.3	58	209.8	99	70.4	140
34.73K	-23	4105	18	773.7	59	203.8	100	68.8	141
32.74K	-22	3922	19	746.3	60	197.9	101	67.1	142
30.87K	-21	3748	20	719.9	61	192.2	102	65.5	143
29.13K	-20	3583	21	694.7	62	186.8	103	64.0	144
27.49K	-19	3426	22	670.4	63	181.5	104	62.5	145
25.95K	-18	3277	23	647.1	64	176.4	105	61.1	146
24.51K	-17	3135	24	624.7	65	171.4	106	59.6	147
23.16K	-16	3000	25	603.3	66	166.7	107	58.3	148
21.89K	-15	2872	26	582.6	67	162.0	108	56.8	149
20.70K	-14	2750	27	562.8	68	157.6	109	55.6	150
19.58K	-13	2633	28	543.7	69	153.2	110		
18.52K	-12	2523	29	525.4	70	149.0	111		
17.53K	-11	2417	30	507.8	71	145.0	112		
16.60K	-10	2317	31	490.9	72	141.1	113		

TABLE 20: 3KΩ Thermistor Resistance

APPENDIX D. TROUBLESHOOTING

Listed below are a few commonly experienced problems and remedial action. These topics are also covered in the **Troubleshooting GeoNet Networks**, **Agent Software Tutorial**, and in the **GeoNet Troubleshooting Guide**, all of which are available at GEOKON's website, https://www.geokon.com. Contact GEOKON if additional assistance is needed.

SYMPTOM: UNIT WILL NOT RESPOND TO COMMUNICATIONS

- U Wrong connection type, or incorrect address specified in Agent software.
- □ The batteries may be improperly installed. Check their placement.
- □ The batteries inside the unit may be dead. Replace the batteries.

SYMPTOM: DATA PRESENT (E.G., BATTERY/SIGNAL STRENGTH) BUT NO VW GAUGE DATA AVAILABLE

- □ Verify that the gauge leads are wired correctly inside the logger. Refer to the gauge manual for wiring information, or to Section 3.5.1.
- Check the gauge for proper operation with an independent readout, such as a GK-404, GK-405, or GK-406. Gauge operation can also be checked by using an ohmmeter to measure the resistance between the VW gauge leads. Very high (megohms) or infinite resistance may indicate cable damage; very low resistance (<20Ω) may indicate a short between conductors.
- \square For long cables, add cable resistance of 14.7Ω per 1000 ft (48.5Ω per km) at 20 °C. Multiply this factor by two to account for both directions.

SYMPTOM: VW GAUGE READING IS UNSTABLE

□ Move any sources of electrical noise away from the transducer cable, such as generators, motors, arc welding equipment, high voltage lines, etc.

SYMPTOM: THERMISTOR DISPLAY SHOWS -273.15 DEGREES C°

- □ This indicates an open circuit to thermistor leads. Verify that the thermistor leads are properly connected inside the logger. For wiring information, refer to Section 3.5.1, or to the gauge manual for wiring information.

SYMPTOM: LOGGER HAS WEAK COMMUNICATION

□ If the signal is consistently weak (indicated by red and green LEDs illuminated at the same time) but not intermittently red, proceed with the installation. If the signal is frequently lost (red flash) it will be necessary to improve it. Try to get the logger as high as possible, with plenty of clear space around the antenna. Extending the sensor cable may enable moving the logger to a better location. If the signal does not improve, a higher gain directional antenna may be necessary. Contact GEOKON for assistance.

SYMPTOM: LOGGER DOES NOT HAVE POWER

- □ Ensure that the polarity of the batteries matches the diagram on the battery holder. Also check that the batteries are firmly seated.
- The batteries may be improperly installed. Check their placement.
- □ The batteries inside the unit may be dead. Replace the batteries.

SYMPTOM: LOGGER WILL NOT SYNCHRONIZE WITH NETWORK

- If the red status light on a logger is flashing at 10 second intervals, it means the logger was once connected to a network, but the network is not present now, or the gateway has been reset, resulting in an equal but not overlapping radio cycle.
- □ Ensure that the network is functioning in deployment mode (red light flashing every 10 seconds on the gateway), and that the channel setting is correct. Follow the steps in Section 4.3 to remove and reinsert the batteries in the logger.

SYMPTOM: NO DATA FROM LOGGER

- □ Be sure logger is powered.
- □ With network in deploy mode, observe either red and green lights only, or green lights every 10 seconds, on the logger.
- □ Make sure network time is set.

SYMPTOM: GREEN LIGHT FLASHES SLOWLY (ONCE PER SECOND)

Bootloader is activated, complete the following:

- 1. Change channel switches to a valid setting.
- 2. Press the Reset button on the circuit board.

SYMPTOM: GREEN AND RED LIGHT ALTERNATING

Device malfunction, contact GEOKON.

APPENDIX E. FIRMWARE UPDATE

WARNING! Performing a firmware update on a logger might reset the logger memory. **Retrieve all data from the network prior to performing a firmware update.**

E.1 PROCEDURE

1. Put the network in deployment mode by pressing the Status button on the gateway. For more information on deployment mode see Section 3.7.

Within three minutes the green LED will flash once every 10 seconds.

- 2. For RS-232 gateways:
 - a. Connect the COM-108 (RS-232 cable) to the 10-pin connector on the gateway.
 - b. Connect the 8001-7 (USB to RS-232 adapter) to the COM-108.
 - c. Connect the 8001-7 to the PC. The figure below shows the completed connection.



FIGURE 37: RS-232 Cable Connection

3. For all other loggers/gateways, connect the COM-166 (Mini USB to STD A cable) to the USB connector on the bottom of enclosure.



FIGURE 38: USB Cable Connection

- 4. Download the '8800 GeoNet Firmware Update Package' from the GEOKON website (https://www.geokon.com/software).
- 5. Right-click on the downloaded file and choose 'Extract All...' from the menu.



FIGURE 39: Choose the 'Extract All' Menu Option

6. When prompted click 'Extract All'.



FIGURE 40: Click the 'Extract All' Button

7. Select a destination for the files and then click 'Extract'.

Co I Extract Compressed (Zipped) Folders
Select a Destination and Extract Files Files will be extracted to this folder:
C:\Users\cfrye\Downloads\GeoNet_Firmware_Update_Utility (1) Browse Image: Show extracted files when complete
Extract Cancel

FIGURE 41: Select the Destination then click the 'Extract' Button

8. Open 'GeoNetUpdateUtility.exe'. If a security warning appears, click 'Run'.



FIGURE 42: Open the GEOKON Update Utility

9. Click 'Select File'.

GeoNet Firmware U	pdater v3 ×
Select File	File:
~	
Program	

FIGURE 43: Click the 'Select File' Button

10. Double click the .txt firmware file. Firmware files are named in the following format: *GeoNet_Firmware_YYMMDD.txt*, where *YY* is the last two digits of the year, *MM* is the month, and *DD* is the day of the month.



FIGURE 44: Select the Firmware Text File

- 11. Using the drop-down box below the 'Select File' button, select the correct serial port for the 8001-7 or COM-166 cable. To identify which serial port the unit is connected to, complete the following:
 - a. Unplug the 8001-7 or COM-166 cable from the PC.
 - b. Go to the Control Panel then open Device Manager.
 - c. Click on the triangle to the left of Ports (COM & LPT) to expand the list.
 - d. Plug the cable back into the computer and the port will appear in the list.

GeoNet Firmware U	pdater v3		×
Select File	File:	GeoNetFirmware_200317.txt	
COM3 COM5	E		

FIGURE 45: Select the COM Port

12. Click 'Program'.

GeoNet Firmware Updater v3			
Select File	File: GeoNetFirmware_200317.txt		
COM5 ~			
Program	E C		

FIGURE 46: Click the 'Program' Button

- A progress bar will appear. The update process will normally take one to two minutes.
- 14. Once the update has finished, operation will return to normal.
- 15. Repeat the above process with all the loggers in the network.

The firmware update is now complete.

E.2 FIRMWARE TROUBLESHOOTING

Perform updates using the GEOKON-provided 8001-7 USB to RS-232 adapter. Other adapters and native serial ports have been unreliable. Make sure the batteries are fresh.

APPENDIX F. SOLAR PANEL KIT

The GEOKON Solar Panel Kit enables you to power a Cellular Gateway in an area that has no access to mains / domestic power.



FIGURE 47: Solar Panel 8900-SOL-10W-BRJ

Inside the kit box are the following:

- One envelope containing technical documents and instructions
- One mounting bracket
- One solar panel complete with power regulation circuitry and power cable



FIGURE 48: Solar Panel Kit Box Contents

INSTALLATION OVERVIEW

The general installation steps are as follows:

- 1. Select a location for the solar panel.
- 2. Assemble and adjust the mounting bracket to the proper angle.
- 3. Install the mounting bracket.
- 4. Secure the solar panel to the mounting bracket.
- 5. Connect the power cable to the gateway.

F.1 SELECT A LOCATION

Choose a location for the solar panel that is clear of obstructions and anything that might cast a shadow on the panel.

F.2 ASSEMBLE THE MOUNTING BRACKET

When assembling the two sections of the mounting bracket, be sure to set the sections to the desired angle before tightening the nuts. The angle of the mounting bracket will dictate the angle of the solar panel.

- Ensure the angle is at least 10 degrees, to aid in water control.
- In general, choose the best angle for the latitude of your location.
- Mounting on a horizontal surface will require a reverse configuration of the two sections compared to mounting vertically. See the figure below.



FIGURE 49: Mounting Options

F.3 INSTALL THE MOUNTING BRACKET

Mount the bracket on a flat surface (roof, wall, etc.) using locally-supplied bolts or lag screws. If mounting to a pole, use locally-supplied U-bolts and retaining clamps.

F.4 SECURE THE SOLAR PANEL TO THE MOUNTING BRACKET

Use the included nuts and screws to secure the solar panel to the mounting bracket. Use the centrally-located holes provided for this purpose on the back of the solar panel.

Note: Be sure to mount the solar panel with the cable coming out the bottom of the panel, as shown below.



FIGURE 50: Centrally-Located Mounting Holes



FIGURE 51: Mounting Bracket Fastened Centrally

F.5 CONNECT THE POWER CABLE

F.5.1 BATTERY SWITCH

Before connecting the power cable, be sure you have set the battery switch appropriately, as indicated in Section 3.2.2.

- When not using an external battery, set the battery switch inside the gateway to the BATTERY setting.
- When using an external battery between the solar panel and the Cellular Gateway, set the battery switch inside the gateway to the 9-24V setting.



FIGURE 52: Solar Panel with External Battery

F.5.2 MAKING THE CONNECTION

Remove the plastic cap from the cable connector, then attach it to the 9-24V plug on the Cellular Gateway. Tighten the retaining ring on the 9-24V plug, for strain relief.

Note: Be sure to implement a drip loop, as indicated in the previous figure, to prevent water ingress through the power connector.



GEOKON 48 Spencer Street Lebanon, New Hampshire 03766, USA Phone: +1 (603) 448-1562 Email: info@geokon.com Website: www.geokon.com GEOKON is an **ISO 9001:2015** registered company