





# Product Tutorial

# Troubleshooting GeoNet Wireless Data Hosting Systems




# Before Continuing

 Many hardware and software issues can be prevented or resolved with a better understanding of the product

Please read the [Installing GeoNet Wireless Data Hosting Systems](#) and [Using Agent Software with GeoNet Wireless Data Hosting Systems](#) tutorials and review the [product manuals](#) prior to attempting to troubleshoot a Network

# Network Tips




# Device Mounting

- Always mount GeoNet devices vertically, with the antenna pointing up
- The space around the antenna should be free of obstructions
- A minimum mounting height of two meters (six-feet) is recommended



# Device Mounting (Continued)

- Obstructions between, around, or near GeoNet devices can cause reflections of the radio signal
- Reflected radio signals can cause GeoNet devices to malfunction
- For optimum performance, create as much space as possible between the straight-line radio path and any obstructions (especially metallic objects)






# Device Mounting (Continued)

- Common mounting mistakes include:
  - ▶ Not enough clear space around the antenna
  - ▶ Mounting devices horizontally
  - ▶ Metallic objects nearby
- The photos to the right show examples of improper device mounting



# Setting Channels

- All GeoNet devices are set to operate on the same channel at the factory

 *Channels only need to be set if multiple networks will be operating within radio range of one another*


- Networks within radio range of one another *must not* be set to the same channel
- Up to 12 Networks can operate in the same area by utilizing a different channel for each Network



# Setting Channels (Continued)

- To set the channels on a device:
  1. Activate Deployment mode
  2. Move the channel switches to one of the 12 valid settings
  3. Press the reset button

⚠ GeoNet Devices can only communicate when set to the same channel, therefore, ALL DEVICES in a network must be set to the same channel



# Deployment Mode

- Must be used when making changes to a network (adding Nodes, changing batteries, resetting a device, etc.)
- Indicated by the LEDs on the Supervisor flashing every 10-15 seconds
- Automatically activated when Supervisor is powered
- Active for 60 minutes by default (Can be changed using Agent software)
- Can be reactivated/reset by pressing the status button on the Supervisor (May take up to 6 minutes to take effect)

# Supervisors Control the Network

- Avoid powering down or removing the Supervisor from a working Network
- If the Supervisor must be powered down or removed, activate deployment mode prior to doing so
- When downloading data via a direct PC connection, bring the PC to the Supervisor rather than removing the Supervisor from the Network




# Battery Replacement

- The Network must be put into deployment mode prior to replacing the batteries in the Supervisor  
(Also best practice when replacing batteries in Nodes)
- Replace D cell batteries when voltage drops below 2.0 VDC
- Replace 12-volt external batteries when voltage is below 11 volts
- All data is stored in nonvolatile flash memory, and will be retained even if the batteries are absent for an extended period
- After replacing the batteries in a Node, make sure it rejoins the Network, then set the Network time using Agent Software  
(Setting time not required when using a Cellular Gateway Supervisor)

# Software Tips

- Changes to “deploy period” will take effect the next time Deployment mode is activated on the Supervisor
- Turn off automatic download before changing the “scan rate”






# Troubleshooting





# Node will not Join the Network: Flashing Red LED

- Make sure the Network is in deployment mode (one or both of the LEDs on the Supervisor flashing **every 10-15 seconds**)
- Verify that all four channel dipswitches inside the Node are set to the same position as the switches inside the Supervisor **Devices will only communicate when set to the same channel**
- Power the Node while it is in close proximity to the Supervisor



# Resetting a Node

- If a Node still will not join the Network after the previous suggestions have been tried, it may be out of synch with the Supervisor
- The Node will join the Network if given enough time, however, the connection can be expedited by resetting the Node
- To reset a Node, press the reset button inside the enclosure, or, hold down the status button until the red and green LEDs turn on, then release the button

# No Signal at Installation Site

- Complete the following:
  1. Make sure the Network is in deployment mode
  2. Power down the Node
  3. Position the Node so that it is in close proximity to the Supervisor (or a Node that has successfully joined the Network)
  4. Power up the Node and wait for it to join the Network
  5. Move the Node to its intended location
- If the Network connection is lost when the Node is in its original location, try to improve the radio signal by completing the steps in the next slide

# Node has a Weak Radio Signal: Red & Green LEDs Flashing Together

- Improve the radio signal by:
  - ▶ Mounting the Node as high as possible
  - ▶ Making sure there is plenty of clear space around the antenna
  - ▶ Removing obstructions from the radio path
  - ▶ Activating more Nodes to provide alternate data paths
  - ▶ Moving the Node to a better location
  - ▶ High gain directional antenna may be required (Contact Geokon)



# Additional LED Light Codes

- **Green LED flashing slowly (once per second):**  
Channel switches inside the Node incorrectly set; move to a valid setting then press the reset button
- **Green LED flashing quickly (twice per second):**  
Update the Network firmware to version 160816 or later  
(Refer to [GeoNet manual](#) for firmware update instructions)
- **Five green flashes then one long red flash (repeating):**  
Update the Network firmware  
(Refer to [GeoNet manual](#) for firmware update instructions)
- **Alternating green & red LEDs:**  
Device malfunction, please contact GEOKON

# Agent Can't Connect to Supervisor: Cellular Gateway

- Ensure that the external power source is connected and functioning properly
- Verify the Supervisor is connected to the cellular network by pressing the status button and observing a green, or green and red flash on the LED indicators
- Make sure the token has been copied into the Network address correctly, and that "token:" has been entered as a prefix

The screenshot displays a web application interface for managing network settings. On the left, a dark sidebar contains a 'projects' menu with options: 'Sample Project', 'list', 'add network', 'add lc2', 'transfer', and 'project settings'. The main content area is titled 'Network Settings' and includes the following fields:

- Name:** A text input field containing 'Sample Network'.
- Network Address:** A text input field containing 'token:SCOMHPKxP/PNnP0hgwwFI'. A green arrow points to this field, and a 'get network settings' button is located to its right.
- Serial Number:** A text input field containing '1537815'.
- Scan Rate:** A dropdown menu set to '10 minutes'.
- Deploy Period:** A dropdown menu set to '1 hour'.
- Description/Notes:** A text area containing 'Devices Installed May 1, 2019'.
- Save:** A button at the bottom left of the form.



# Agent Can't Connect to Supervisor: Direct Cable Connection

- Check the cable connection between the computer and the Supervisor
- Verify that the COM port entered as the “Network Address” in the Network Settings is correct

The screenshot displays the 'Network Settings' configuration window. On the left, a sidebar lists project actions: 'projects', 'Sample Project', 'list', 'add network', 'add lc2', 'transfer', and 'project settings'. The main panel is titled 'Network Settings' and contains the following fields:

- Name:** Sample Network
- Network Address:** COM\_ (highlighted with a green arrow)
- Serial Number:** 1537815
- Scan Rate:** 10 minutes
- Deploy Period:** 1 hour
- Description/Notes:** Devices Installed May 1, 2019

Buttons include 'get network settings' (top right), 'Save' (bottom left), and 'add network' (bottom left sidebar).

- Make sure the D cell batteries in the Supervisor are installed correctly and are not depleted

# No Data from a Node

- Make sure the Node is powered on, and that it has successfully joined the Network
- Click “set network time” in the Network settings screen

The screenshot displays the 'Network Settings' interface. On the left is a sidebar with a tree view containing 'Sample Project', 'Sample Network', 'nodes', 'network settings' (highlighted), 'export', and 'live'. The main content area is titled 'Network Settings' and contains several input fields: 'Name' (Sample Network), 'Network Address' (COM9), 'Serial Number' (1537815), 'Scan Rate' (10 minutes), 'Deploy Period' (1 hour), and 'Description/Notes' (Devices Installed on May 1 2019). Below these is a 'Network Time Zone' dropdown menu set to '(UTC-05:00) Eastern Standard Time (uses daylight savings)'. A 'Save' button is at the bottom left of this section. Below the main settings is a 'Network Time' section with the text 'To get network time use the "get network settings" button'. It shows the 'Current Network Time' as 'Thu Sep 27 2018 13:13:40 GMT-0400' and a 'set network time' button, which is highlighted with a green arrow. To the right of this is a 'Set Project' section with a 'Project' dropdown menu set to 'Sample Project' and a 'Save' button.

- Make sure the D cell batteries are installed correctly and are not depleted

# No Data from a Node (Continued)

- Take a test reading by pressing the status button on the Supervisor  
(Reading will be available for download within the next 6 minutes, depending on radio cycles and Supervisor type)
- If necessary, data can be retrieved directly from a Node:
  1. Connect a PC to the USB port
  2. Create a new network in Agent
  3. Enter the COM port the Node is connected to as the Network Address
  4. Download the data

# Vibrating Wire Sensor Reading is Missing, Incorrect, or Unstable

- Verify that the gauge leads are wired correctly inside the Node (Refer to the [GeoNet manual](#) for wiring information)
- Multi-channel and addressable Nodes stop trying to read empty channels after two attempts; additional attempts occur at the top of every hour (Reset the Node to initiate an immediate retry)
- Move any sources of electrical noise away from the transducer cable (generators, motors, arc welding equipment, etc.)
- Check sensor operation with a readout (GK-404, GK-406, etc.) or by measuring the resistance between the gauge leads with an ohmmeter
  - ▶ Very high or infinite resistance may indicate cable damage
  - ▶ Very low resistance may indicate a short between conductors

# Thermistor Reads $-273.15\text{ }^{\circ}\text{C}$

- Indicates an open circuit to thermistor leads
- Verify the thermistor leads are wired correctly inside the Node (Refer to the [GeoNet manual](#) for wiring information)
- Measure the resistance between the thermistor leads with an ohmmeter
  - ▶ Resistance should be between  $10\text{K } \Omega$  and  $2.4\text{K } \Omega$  when the ambient temperature is between  $0$  and  $+30\text{ }^{\circ}\text{C}$
  - ▶ Very high or infinite resistance may indicate cable damage
  - ▶ Very low resistance may indicate a short between conductors

# For more information...

- Consult the GeoNet and Agent instruction manuals.
- Instruction manuals are available for download at:  
[www.geokon.com/Manuals](http://www.geokon.com/Manuals)
- Please visit <https://www.geokon.com/Tutorials> for more tutorials